


图例

- | | |
|---------------------------|---|
| 1-止回阀 | 1-Non return valve |
| 2-排气截止阀 | 2-Discharge shut-off valve |
| 3-高压接头1/4" SAE-FLARE | 3-High pressure gas 1/4" SAE-FLARE |
| 4-吸气截止阀 | 4-Suction shut-off valve |
| 5-接线盒 | 5-Electrical box |
| 6-油冷却器接口5/8"SAE-FLARE | 6-Oil cooling connection 5/8"SAE-FLARE |
| 7-电磁阀 (无级 有级转换) | 7-Solenoid valves (step-stepless transform) |
| 8-能调电磁阀 | 8-Solenoid valves for part-load operation |
| 9-油过滤器 | 9-Oil filter |
| 10-油加热器 | 10-Crankase heater |
| 11-温度传感器1/8"NPT | 11-oil temperature sensor 1/8"NPT |
| 12-注油/放油阀3/8" SAE-FLARE | 12-Oil fill/drain valve 3/8" SAE-FLARE |
| 13-油位开关 (选配) | 13-Oil level control (optional) |
| 14-油视镜 | 14-Oil sight glass |
| 15-油压接头1/4" SAE-FLARE | 15-Oil pressure 1/4" SAE-FLARE |
| 16-Vi控制电磁阀 (选配) | 16-Vi adjust solenoid valves (optional) |
| 17-低压接头1/4" SAE-FLARE | 17-Low pressure gas 1/4" SAE-FLARE |
| 18-低压侧放油M14 | 18-Oil drain motor housing M14 |
| 19-喷液接口010/经济器接口042 (选配件) | 19-Liquid injection010/Eco connection042 (optional) |

